



Intel® SoC Watch for Linux* Release Notes

September 2025

Version 2025.6

Intel Corporation

www.intel.com

[Legal Information](#)

Contents

Legal Information	3
Version History	4
Customer Support.....	7
 Chapter 1: Introduction	
 Chapter 2: New in This Release	
 Chapter 3: System Requirements	
Supported Architectures	10
Dependencies	10
 Chapter 4: Where to Find the Release	
 Chapter 5: Installation Notes	
Extracting the Intel SoC Watch Package.....	13
Intel SoC Watch Prerequisites for Yocto and Wind River* Linux.....	13
Build the Kernel Modules	14
Building Linux* Kernel Modules	15
Install Intel SoC Watch.....	15
Intel SoC Watch for Linux* Installation.....	15
Key Files	16
Remove the Intel SoC Watch Drivers	16
 Chapter 7: Known Issues	
 Chapter 8: Related Documentation	
 Chapter 9: Acronyms and Terms	

Legal Information

Intel technologies may require enabled hardware, software or service activation.

No product or component can be absolutely secure.

Your costs and results may vary.

© Intel Corporation. Intel, the Intel logo, and other Intel marks are trademarks of Intel Corporation or its subsidiaries. Other names and brands may be claimed as the property of others.

Performance varies by use, configuration and other factors. Learn more at www.Intel.com/PerformanceIndex.

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document.

The products described may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Intel disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade.

Intel, the Intel logo, Intel Atom, Intel Core, Intel Xeon Phi, VTune and Xeon are trademarks of Intel Corporation in the U.S. and/or other countries.

Microsoft, Windows, and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Java is a registered trademark of Oracle and/or its affiliates.

OpenCL and the OpenCL logo are trademarks of Apple Inc. used by permission by Khronos.

© **Intel Corporation**

Version History

These are the main releases of Intel® SoC Watch:

Date	Revision	Description
June, 2019	2.11	Improves handling of unrecognized CPUs, reporting S-state when hibernation occurs, and other bug fixes.
September, 2019	2019.12	Added support for Intel platform code named Ice Lake. Modified hw-cpu-pstate reporting.
October, 2019	2019.13	Fixed issue in hw-cpu-pstate for Intel platform code named Ice Lake.
November, 2019	2020.1	Added support for Intel platform code named Comet Lake.
February, 2020	2020.2	Added collection of tool usage analytics. Added new features pch-slps0, pch-slps0-dbg. Improved error messages and help output. Enhanced driver security.
June, 2020	2020.3	Bug fix release.
July, 2020	2020.3.1	Bug fixes
September, 2020	2020.3.2	Bug fixes .
October, 2020	2020.4	Added support for Intel platform code named Tiger Lake. Added support dgfx-pwr support for discrete graphics card code named DG1. Added non-root user support. Added topology label in reports for some metrics. Re-named feature cpu-gpu-concurrency to cpu-igpu-concurrency. Removed support for older platforms.
November, 2020	2020.5	Changed hw-cpu-pstate to report frequencies per thread rather than per core. Added term <i>integrated</i> to hw-igfx-cstate and hw-igfx-pstate report titles. Fix for hw-cpu-cstate reporting of core concurrency.
April, 2021	2021.1	Added system name, OS name, and Intel PMT GUID to output reports. Included throt-rsn and other sampled count results in Automation_Summary. Re-ordered feature reports in summary output. Updated socwatch driver to build for Linux 5.12.
July, 2021	2021.2	Bug fix release.
September, 2021	2021.3	Added PMT-based metric support when using Linux kernel v5.11.
October, 2021	2021.3.1	Improved support for platforms with many sockets and/or discrete graphics cards. Modified option --update-usage-consent.
November, 2021	2021.4	Added support for Intel platforms code named Rocket Lake and Tiger Lake - H.

Date	Revision	Description
		Added support for Intel platforms code named Ice Lake -X and Cooper Lake -X. Bug fixes.
February, 2022	2022.1	Added support for Intel platform code named Alder Lake and Intel® Arc Discrete Graphics Card . Bug fixes.
April, 2022	2022.2	Bug fixes.
June, 2022	2022.3	Bug fixes.
August, 2022	2022.4	Bug fixes.
September, 2022	2022.5	Bug Fixes.
November, 2022	2022.6	Report complete topology path on hybrid systems. Bug fixes for data correctness.
January, 2023	2023.0	Deprecation of Google Analytics support. Bug fixes for data correctness.
February, 2023	2023.1	Bug fixes for data correctness.
April, 2023	2023.2	Added support for Intel platform code named Raptor Lake. Added support for Intel server platform code named Sapphire Rapids -Xeon. Bug fixes.
June, 2023	2023.3	Bug fixes.
August, 2023	2023.4	Bug fixes
October, 2023	2023.5	Change in scope for certain group features including -f sys.
November, 2023	2023.6	Added support for Intel server platform code named Emerald Rapids-Xeon. Bug Fixes
December, 2023	2023.7	Bug fixes.
January, 2024	2024.0	Enabled additional features support on Intel platform code named Meteor Lake.
February, 2024	2024.1	Bug fixes.
April, 2024	2024.2	Deprecation of support for older atom based features. Bug Fixes
May, 2024	2024.3	Enabled support for Intel discrete graphics code named Ponte Vecchio. Enabled support for the feature hw-cpu-hwp on Intel server platforms. Bug Fixes
July, 2024	2024.4	Bug fixes including data correctness issue in the feature sata-lpm.

Date	Revision	Description
September, 2024	2024.6	Added support to Intel platforms code named Elkhart Lake, Arrow Lake and Lunar Lake. Bug Fixes
October, 2024	2024.7	Additional features support on Intel Platform code named Lunar Lake Added support for option --result-slice-range. Bug Fixes
November, 2024	2024.8	Bug Fixes
January, 2025	2025.0	Bug fixes including an issue with the help output.
February, 2025	2025.1	Enabled support for Intel® Arc™ B-series graphics. Enabled support for the feature memss-pstate on Intel platform code named Lunar Lake. Bug fixes
April, 2025	2025.2	Added support for Intel server platforms code named Granite Rapids and Sierra Forest.
April, 2025	2025.3	Added support for latest Pcode telemetry GUID on Intel support for Intel® Arc™ B-series graphics.
May, 2025	2025.4	Added support for latest Pcode telemetry GUID on Intel support for Intel® Arc™ B-series graphics.
July, 2025	2025.5	Enabled additional features support for Intel platform code named Panther Lake PCD P. Enabledsupport for Intel platforms code named Panther Lake PCD H and Wildcat Lake. Bug fixes.
September, 2025	2025.6	Improved the topology report for hybrid platforms including core type.

Customer Support

For technical support, including answers to questions not addressed in this product, Intel® oneAPI IoT Toolkit forum (<https://community.intel.com/t5/Intel-oneAPI-Base-Toolkit/bd-p/oneapi-base-toolkit>).

Introduction

Intel® SoC Watch is a data collector for power-related data that can help identify issues on a platform that prevent entry to power-saving states. Captured metrics include:

- System sleep states
- CPU and GPU sleep states
- Processor frequencies
- Temperature data
- Device sleep states

You can correlate the collected data and visualize over time using Intel®VTune Profiler.

This document provides system requirements, installation instructions, issues and limitations, and legal information.

To learn more about this product, see:

- New features listed in the [New in This Release](#) section below, or in the help.
- Reference documentation listed in the [Related Documentation](#) section below
- Installation instructions can be found in the [Installation Notes](#) section below.
- For a detailed quick start guide to running the tool, see the *Intel SoC Watch User's Guide* in your installed documentation.

Optimization Notice

Intel's compilers may or may not optimize to the same degree for non-Intel microprocessors for optimizations that are not unique to Intel microprocessors. These optimizations include SSE2, SSE3, and SSSE3 instruction sets and other optimizations. Intel does not guarantee the availability, functionality, or effectiveness of any optimization on microprocessors not manufactured by Intel. Microprocessor-dependent optimizations in this product are intended for use with Intel microprocessors. Certain optimizations not specific to Intel microarchitecture are reserved for Intel microprocessors. Please refer to the applicable product User and Reference Guides for more information regarding the specific instruction sets covered by this notice.

Notice revision #20110804

New in This Release

2

The 2025.6 release (*socwatch* driver v2.16.7) contains these changes:

- Improved the topology report of the hybrid systems. The summary report now provides information about the core type (P Core, E core, L/P core).

System Requirements

Supported Architectures

Intel SoC Watch supports these Intel® microarchitecture or platform code names:

- Denverton
- Elkhart Lake
- Sky lake
- Kaby Lake
- Coffee Lake
- Whiskey Lake
- Amber Lake
- Comet Lake
- Ice Lake
- Tiger Lake
- Rocket Lake
- Alder Lake
- Raptor Lake
- Meteor Lake
- Lunar Lake
- Arrow Lake
- Granite Rapids-Xeon
- Sierra Forest
- Emerald Rapids
- Skylake-Xeon
- Cascade Lake-Xeon
- Ice Lake-Xeon
- Sapphire Rapids-Xeon
- Cooper Lake-Xeon

Intel SoC Watch supports these Intel® Discrete Graphics code names:

- DG1
- Intel® Arc™ A-series graphics
- Intel® Arc™ B-series graphics
- Ponte Vecchio

Dependencies

Intel SoC Watch depends on specific OS configurations and hardware capabilities. If these are not present on the target system, Intel SoC Watch may fail to work properly.

- Linux Kernel version needs to be 2.6.32 or later.
- GNU C Library version must be GLIBC_2.28 or later.
- `KERNEL_CONFIG_TRACEPOINTS` must be enabled.
- Kernel should be compiled with "`CONFIG_MODULES`" enabled.
- P States
 - Kernel config `CONFIG_X86_SFI_CPUFREQ` or `CONFIG_X86_ACPI_CPUFREQ` must be enabled (i.e. set to 'y' or 'm').
 - One of these pstate drivers must be utilized: `sfi-cpufreq`, `acpi-cpufreq`, or `intel_pstate`. To determine which driver is loaded, check the `sysfs /sys/devices/system/cpu/cpu0/cpufreq/scaling_driver` file.
 - If one of these pstate drivers is not loaded, the kernel needs to be reconfigured and recompiled.
- C States

- Kernel config CONFIG_TIMER_STATS must be enabled.
- Kernel config CONFIG_INTEL_IDLE must be enabled and the intel_idle kernel module has to support the core of the target platform.
- To determine if the intel_idle kernel module is loaded, check the sysfs `/sys/devices/system/cpu/cpuidle/current_driver` file. It must equal `intel_idle`. If it equals `acpi_idle`, only C0 and C1 will be used by the core.

Where to Find the Release

Intel® SoC Watch is available in Intel® oneAPI Base Toolkit as a part of Intel® VTune™ Profiler (<https://software.intel.com/content/www/us/en/develop/tools/oneapi/base-toolkit>).

Installation Notes

5

Intel SoC Watch for Linux* OS is installed as part of the Intel® VTune™ Profiler, which is included in the Intel® oneAPI Base Toolkit. Intel SoC Watch is used by Intel® VTune™ Profiler for collecting certain analysis, but it is also a standalone tool. Following are instructions for setting up Intel SoC Watch for standalone use.

Prerequisites for Intel® PMT and Discrete Graphics Metric Collection Using Intel SoC Watch

Collection of metrics that use the Intel Platform Monitoring Technology (PMT) as the data source require Intel SoC Watch being able to connect to Intel® PMT through a sysfs interface or driver-to-driver interface. The discrete graphics cards store telemetry in this space, so this access is required for collecting dgfx* metrics, as well as for Intel® PMT-based core metrics.

The Intel® PMT sysfs interface is first included in the up-streamed Linux kernel v5.11. Therefore, if you are running on a platform with v5.11 kernel or newer, you can collect Intel® PMT-based metrics in SoC Watch *driverless* mode (i.e., when the socwatch driver is *not* loaded). Use of this interface requires running the SoC Watch collection with root privilege. If the socwatch driver is loaded, SoC Watch will try to use the driver-to-driver interface (which is not yet available in an up-streamed kernel) and report the Intel® PMT-based features as unknown.

Extracting the Intel SoC Watch Package

Intel SoC Watch must be installed on the target system (the system to be analyzed). To extract and install the package, the user should have sudo (root) privilege.

When Intel® oneAPI BaseToolkit is used to install Intel® VTune™ Profiler and it is installed directly on the target system:

Intel SoC Watch will already be extracted and is located in `/opt/intel/oneapi/vtune/<oneAPI-release-version>/socwatch`.

The Intel SoC Watch release notes and user's guides are located in `/opt/intel/oneapi/vtune/<oneAPI-release-version>/documentation/en/socwatch`.

When Intel® oneAPI BaseToolkit is used to install Intel® VTune™ Profiler and it is installed on a host system:

Intel SoC Watch will need to be copied to the target system and extracted. The install package is located on the host system at `/opt/intel/oneapi/vtune/<oneAPI-release-version>/target/linux/vtune_profiler_target_x86_64.tgz`. Copy `vtune_profiler_target_x86_64.tgz` to the target system and extract it into directory `/opt/intel` using command `tar zxvf vtune_profiler_target_x86_64.tgz -C /opt/intel/`.

The release notes and user's guide are not included in this package. They are located on the host system in `/opt/intel/oneapi/vtune/<oneAPI-release-version>/documentation/en/socwatch`.

You must build the kernel modules and install the SoC Watch driver to enable collection of all metrics. See instructions below.

Intel SoC Watch Prerequisites for Yocto and Wind River* Linux

The Intel SoC Watch binary is a C++ program that requires `libstdc++` to be present on the target system in order to function. Although most Linux distributions provide this by default, there are some minimal distributions of Yocto and Wind River Linux that may not.

To check if your OS image contains `libstdc++`, run this command:

```
find / -name "libstdc++"
```

If the library is present, you should see an output similar to:

```
/usr/lib64/libstdc++.so.6
```

If you see no output, the required library is missing. To fix this, do one of these steps:

- Rebuild Yocto or Wind River Linux with an option to include libstdc++.so file in the image.
- Provide the library file directly to Intel SoC Watch.

Rebuild OS image to include libstdc++.so file

1. Open the projectDir/local.conf file in a text editor.
2. Add the library with the IMAGE_INSTALL_append option and save the file:

```
IMAGE_INSTALL_append = " libstdc++"
```

NOTE Make sure that you include the leading space as it will be concatenated with any libraries previously added in a list.

3. Rebuild the platform project by running the following command from the projectDir:

```
make
```

Once the build completes, the library will be part of the project image rootfs. Proceed with reflashing the OS image to the target system and subsequently installing Intel SoC Watch.

Provide libstdc++.so library file directly to Intel SoC Watch

If you are unable to rebuild the OS image, but are able to obtain a valid libstdc++.so file (you can copy it from another system or build it yourself):

1. Unpack the SoC Watch package.
2. Copy the file into the /libs subfolder where it will be picked up at runtime.

libgcc_s.so Library

Some minimal Yocto distributions may also lack another library: libgcc_s.so. In this case, follow either of the aforementioned solutions.

Build the OS and include the image:

Use this command when building the OS.

```
IMAGE_INSTALL_append = " libgcc_s"
```

Copy file into Intel SoC Watch package:

Copy the library libgcc_s.so file into the /libs folder of the Intel SoC Watch package.

Build the Kernel Modules

If the Intel SoC Watch kernel modules (i.e. device drivers) are not present in the OS image of the target system, you will need to build and possibly sign them. Building and signing device drivers requires access to the kernel build directory for the OS image running on your target device as well as all the required *userspace* packages to compile the drivers. A kernel build directory is generated while building the OS image of the target system.

When all required *userspace* packages for compiling the kernel modules are not installed you will see errors indicating build tools (e.g., *make*) are not found, for example: `make: command not found`. These must be installed on the host system being used for the build. For rpm-based package manager distributions a solution could be: `sudo yum group install "Development Tools"`. For Debian* OS package manager

distributions a solution could be: `sudo apt-get install build-essential`. An online search for your OS distribution type regarding which packages are required to build the Linux OS kernel will provide more information.

When building the kernel modules, do not open (or unzip) the Intel SoC Watch package (i.e. tar.gz file) on a Windows* based system then copy to a Linux system. The package must be extracted on the Linux build system using the unzip command to make sure the build scripts and make files are unmodified.

If a kernel is built with the CONFIG_MODULE_SIG kernel config enabled, any device driver loaded into that kernel must be signed with the same keys used to build the kernel. In general, drivers built for Linux targets do not need to be signed and the following description assumes the drivers do not need to be signed. But, if an end user tries to load an unsigned driver into a kernel that requires signed drivers, the `insmod` command will fail with the error "Required key" not available or "Operation not permitted". If the signing key from the running kernel is not available, disable secure boot in the system BIOS menus. The BIOS menus can be inspected to determine if your system has secure boot enabled. Also, some Linux* OS distributions have utility `mokutil` available that reports the secure boot state (see the `mokutil` man page for installation steps and usage). If a signed driver is loaded into a kernel that does not require signed drivers, the load will succeed.

Building Linux* Kernel Modules

Linux kernel modules may only be built after the Intel SoC Watch package and kernel headers are copied to and installed on the target. See the section [Intel SoC Watch for Linux Installation](#) below for instructions on how to build the kernel modules for a target device running Linux.

Install Intel SoC Watch

Host: laptop, desktop, or server used to communicate with target device.

Target: device to be analyzed with Intel SoC Watch.

Intel SoC Watch for Linux* Installation

If Intel SoC Watch was previously installed on the target, delete the `socwatch_linux_*` directory before installing a new version. Then, perform the following steps on the target device.

1. Login to the target as root:

```
ssh root@<your_target_IP>
```

2. Identify the <install-dir> where SoC Watch was installed as indicated below. Note that the SoC Watch driver build must be executed on the OS kernel that matches the target and the driver install must be executed on the target system. If Intel SoC Watch was installed on a host system, then it must be copied to the target before proceeding. (See [Extracting the Intel SoC Watch Package](#))

a. *Host system:* `/opt/intel/oneapi/vtune/<oneAPI-release-version>/`

b. *Target system:* `/opt/intel/vtune_profiler_target`

3. Navigate to the Intel SoC Watch directory:

```
cd <install-dir>/sepd/src
```

4. Use the following commands to build the SoC Watch driver:

a. To build the driver.

```
./build-drivers -ni (switch "ni" refers to "No User Interface")
```

b. Reload the module to load the SoC Watch driver.

```
./insmod-sep -r
```

c. To verify if SoC Watch driver is loaded, use the below command to query.

```
./insmod-sep q
```

5. Use the below command to configure SoC Watch collection environment . To run on

a. *Host system:* `source <install-dir>/vtune-vars.sh`

- b. *Target system:* `source <install-dir>/sep_vars.sh`
- c. To set the environment variable, use the following command (The <install-dir> should be based on the host/target system.)

```
export PATH=<install-dir>/socwatch/x64:$PATH
```

NOTE Sourcing of `vtune-vars.sh` or `sep_vars.sh` is required if `/opt/intel/oneapi/setvars.sh` is not already sourced as a part of Intel® System Bring-up Toolkit installation.

Key Files

The following table describes the key files.

File	Description
<code>build_drivers.sh</code>	The build script used to build all of the device drivers utilized by Intel SoC Watch.
<code>socwatch2_x.ko</code>	The Intel SoC Watch kernel module used to collect both hardware and kernel data at runtime.
<code>setup_socwatch_env.sh</code>	The script used to setup the Intel SoC Watch runtime environment.
<code>socwatch</code>	The Intel SoC Watch executable built as a native application. Use this file to collect data and generate additional results from a raw SW2 file.
<code>SOCWatchConfig.txt</code>	The Intel SoC Watch configuration file. The configuration file is read by Intel SoC Watch immediately before each collection. It contains hardware addresses utilized by the device driver during the collection.
<code>EULA.txt</code>	End User License Agreement file.
<code>third-party-programs.txt</code>	List of third party programs included in the package.
<code>plugins/libSWCore.so</code>	A library providing Intel SoC Watch functionality.

Remove the Intel SoC Watch Drivers

Remove Intel SoC Watch drivers using the `rmmmod` command. For example: `rmmmod socwatch2_13`.

Known Issues

7

Bandwidth

- The presence of EDRAM on a system may not be detected by Intel SoC Watch. This is known to occur when the accelerator card VCA2, which contains EDRAM, is present.
- Total DDR bandwidth does not include EDRAM. On systems using EDRAM, the `ddr-bw` feature report may have a discrepancy between the total data reads and writes and the total component requests. The Data Reads+Data Writes will be significantly higher than the total IA+GT+IO requests, because the EDRAM requests are not included.

C-States / P-States

- When collecting a trace of residency data from hardware counters (i.e., using `-m`), the summarized residency data could be 2-3% inaccurate due to error propagation in the accumulation of each sample's calculated residency. Collecting without `-m` results in greater accuracy because only a single sample is taken. However, long collection duration could result in a counter rollover, and that will not be detected without the use of `-m`.
- On Intel Atom® platforms, if all cores in a module request C6FS but actual sleep time is short, the Auto-Demotion logic of the hardware resolves the module state to module C0. Consequently, you may find module C0 to be greater than the sum of core C0 and C1 on all the cores in a module. On the same lines (auto demotion at the package level), the package C0 may be greater than module C0 residencies of the two modules.
- During the transition time from core C1/C1e/C6 to core C0, a core may run in LFM which will be properly measured by Intel SoC Watch. Therefore, results that include a large number of C1/C1e/C6 residencies may show a lower PState than expected.

Discrete Graphics

Miscellaneous

- On systems configured to enter deep sleep, feature `-f acpi-sstate` reports residency in S3 state but should report that time as S0 because deep sleep uses S0ix states for current Intel architectures.
- Intel SoC Watch displays a confusing error message when it cannot collect a feature due to missing drivers (e.g., when both the Intel SoC Watch driver is not loaded and the Linux kernel MSR driver is not loaded). For example, the message given when `hw-cpu-cstate` cannot be collected in this case is: *ERROR: WARNING: feature hw-cpu-cstate CANNOT be collected without "-m, --max-detail" switch!.* One of these drivers must be loaded to resolve this issue.
- When running on Linux Yocto OS, Intel SoC Watch will simply return without executing unless you create a symbolic link for `/lib64` pointing to `/lib`.
- If collecting a large number of metrics and requesting multiple types of results files to be generated on the same command line, Intel SoC Watch may report the following, *Warning: Could not post process metric data: Too many open file handles. Results may be incomplete for some metrics. Try post processing results with only one -r option at a time. If the problem persists; try collecting fewer metrics.* There will be some missing reports in the results files that are generated if this occurs. The work around is to specify only one `-r` file type at collection time or collect fewer metrics. After collection, use `-i` option with each of the remaining file types to generate the additional result files. This issue is also seen in server platforms with more cores.
- Metrics report Unknown 0 when `-m` is not used and hibernation occurs. Metrics with a snapshot default collection mode, such as CPU C-state, will show the Unknown state with 0 time and the remaining states will not sum to the total collection duration if the system entered hibernation during the collection and the

`-m` option was not specified. The snapshot metrics are only collected at the start and end of a collection by default, but finding hibernation time requires samples taken throughout the collection. Including `-m` will cause continuous sampling to occur for all metrics. When hibernation occurs, a message reporting time spent in hibernation appears at the beginning of the summary report. The Unknown state is then included for all appropriate metrics and the time in hibernation is included in that state. Refer to the *Intel SoC Watch User's Guide* "Options Quick Reference" section to learn which metrics have a snapshot collection mode by default.

- Permission issues with SELinux will cause Intel SoC Watch collection to fail. Some distributions enable SELinux by default. If you have the following file your system may have SELinux enabled:

```
/selinux/enforce
```

If that file exists, you can disable by issuing:

```
echo 0 > /selinux/enforce
```

- Syntax errors in the command line may not report a visible error message. If a collection did not run and you are not seeing any error message, add option `-d 2` to your command line to get more information.

Intel® VTune™ Profiler Visualization

- Importing a collection that includes feature `-f dgfx-pwr` to Intel® VTune™ Profiler may fail with "Database interface, Precompute error". This issue was first seen with Intel® VTune™ Profiler v2020 Update 3.
- When using Intel® VTune™ Profiler to view `ddr-bw` data collected by Intel SoC Watch, the Intel VTune Profiler summary report may not match the SoC Watch summary report. If this occurs, the SoC Watch summary results are correct. This issue has been seen on platforms prior to Intel platform code named Tiger Lake.
- The Intel VTune Profiler System Summary does not report the rated frequency for the CPU when viewing results from data collected by Intel SoC Watch, such as Throttling Analysis. Instead, it reports 1GHz which is the clock frequency used in the calculations for processing the SoC Watch data.
- If the bandwidth is 0 Mb throughout the collection for a particular bandwidth type, Intel VTune Profiler will not show a timeline entry for it. The timeline is shown only if there is at least one non-zero value.
- In some cases, the summary CSV results produced by Intel SoC Watch can vary from the summary results shown by Intel VTune Profiler even though they represent the same collection. For example, the summary CSV file may report a specific `cpu-pstate` residency of 50.78% and Intel VTune Profiler may report the same `cpu-pstate` residency as 50.8%.
- Intel VTune Profiler currently does not support bandwidth ranges used for `ReadPartial` and `WritePartial`. In order to keep the visualization consistent with Intel SoC Watch v1.x, Intel VTune Profiler uses the upper bound of the range to visualize the bandwidth.
- In order to visualize graphics C-states that are reported as `Render` and `Media`, the table headers in the trace file (generated with option `-r int`), must be manually modified, adding *Render* and *Media* to the appropriate C0, C1, and C6 column headers.

Related Documentation



The release contains these documents:

- Intel® SoC Watch User Guide for Google Android* and Linux* OS
- Energy Analysis help (<https://software.intel.com/content/www/us/en/develop/documentation/energy-analysis-user-guide>)

Acronyms and Terms

The following acronyms and terms are used in this document (arranged in alphabetic order):

Acronym/Term	Description
DDR	Double Data Rate
Intel® PMT	Intel® Platform Monitoring Technology
SoC	System on Chip